

User's Manual

INTRODUCTION

This Expresscard or PCI-Express 2.0 to USB 3.0 Host Controller Card supports Super Speed USB 3.0 standard, operating at 5 Gbps full-duplex mode, is 10 times faster than USB 2.0 High-Speed (480 Mbps) standard and is also backward compatible with current USB 2.0 devices.

FEATURES AND SPECIFICATION

General

- Based on Etron EJ168A USB 3.0 Host Controller IC
- Compliant with Extensible Host Controller Interface (xHCI) Specification Revision 1.0
- Compliant with PCI Express Base Specification 2.0
- Supports PCI-Bus Power Management Interface Specification Revision 1.2
- Microsoft drivers for Windows 7 / Vista / XP / Server 2008 32-/64-bit OS

PCI-Express to USB 3.0 Host Controller Card Model (*)

- PCI-Express 2.0 1-Lane (x1) interface with data transfer rate up to 5Gbps
- Backwards compatible to PCI-Express 1.0a with data transfer rate up to 2.5Gbps
- Supports Standard and Low-profile desktop computer
- Internal HDD power connector for supplying extra +5V power to the USB ports
- Internal HDD power connector LED indicator: Lights up when USB bus power is supplied from the HDD power connector connected to the power supply unit (PSU).

ExpressCard to USB 3.0 Host Controller Card Model (*)

- Compliant with PCI ExpressCard Revision 1.0
- Fully Plug-&-Play and Hot Plug supported
- +5V DC power jack to provide extra power for high power USB devices

USB Interface

- Compliant with Universal Serial Bus 3.0 Specification Revision 1.0
- Provides USB 3.0 Super-Speed (5 Gbps) host port, backward compatible with USB 2.0 High-Speed (480Mbps), Full-Speed (12Mbps) and Low-Speed (1.5Mbps) interface
- Supports all USB compliant data transfer types (Control / Bulk / Interrupt / Isochronous)
- Supports all USB compliant peripherals (e.g. keyboard, mouse, monitor, joystick, etc.)
- Full support of real time dynamic insertion and removal of USB devices

PACKAGE CONTENTS

Please check whether the package contains following items. If any item is missing or damaged, please contact the retailer as soon as possible:

- Expresscard or PCI-Express 2.0 to USB 3.0 Host Controller Card x 1
- Driver CD x 1
- User Manual x 1
- Optional 3.5mm 5V DC cable x 1
- Optional 5.5mm 12V DC cable x 1
- Optional Power cable x 1 (**)
- Optional Universal AC to DC 5V adapter x 1 (**)

SYSTEM REQUIREMENT

- Motherboard with one available x1, x4, x8 or x16 PCI-Express 1.0 / 2.0 slot.
- Notebook with one available Expresscard slot (**)
- PCI Express 2.0 interface is recommended for fully utilizing the USB 3.0 (5 Gbps) bandwidth.
- Supported operation system
- Optical drive for driver installation

WARNING

Before installing and activating the controller card, please make sure you have a complete backup of your existing data from hard drives. Manufacturer is not responsible for data loss due to abuse, misuse, or neglect. Should you have any installation problem, please contact your dealer for assistance.


HARDWARE INSTALLATION

For PCI-Express to USB 3.0 Host Controller Card model (*):

1. Turn off your computer and all external devices connected to it and
2. Disconnect your computer from the power sources.
3. Open the computer case. Refer to your computer user manual for more details.
4. Locate an available PCI-Express slot (preferably a PCI Express 2.0 slot) and remove the slot bracket. Save the bracket screw for later use.
5. Align the controller card horizontally with respect to the PCI-Express slot and insert it into the slot firmly and evenly.
6. Once you have properly positioned the card into the slot, fasten it to the computer case with the bracket screw you have saved.
7. Please connect the power supply unit (PSU) of the computer to our product.
8. Secure the computer case and switch on your computer.
9. For some models, there will have a 5V DC jack or a 12V DC jack output socket on the card.
The 5V DC or 12V DC powered device can get the power from the DC Jack on those models by using the DC power cable provided. Third party's DC cable is not recommended as the polarity may differ.

For ExpressCard to USB 3.0 Host Controller Card model (*):

1. Insert the ExpressCard adapter into the ExpressCard slot on your computer.
2. If you use a third party's +5V DC power supply, make sure the polarity of the DC power supply plug is correct. See below figure for the indication of +5V and Ground polarity:



3. To get extra power for high-current USB device such as 2.5" hard drive enclosure, connect the optional "Power cable" or DC +5V adapter to the DC power jack on the product.

DRIVER INSTALLATION

Installing Windows 7 / Vista / XP / Server 2008 32-/64-bit driver:

1. Insert the driver CD into your optical drive. Assume the optical drive letter is **D:**.
2. Go to the driver folder **D:\Etron\EJ168**
3. Double click on "**setup.exe**"
4. The Installation Wizard will guide you through the setup process. Follow the on-screen instruction until the installation is completed.

Verifying Driver Installation

Make sure the following items appear in the Universal Serial Bus Controllers category in the Windows Device Manager, and there is no yellow exclamation mark, then you have successfully installed the driver for the product.

Etron USB 3.0 Extensible Host Controller
Etron USB 3.0 Extensible Root Hub

GETTING THE LATEST DRIVER, SOFTWARE & DOCUMENT

1. Visit <http://www.drivers-download.com>
2. In "**Drivers Search**" section, enter the Download code (DL code): **DL-0430001** to search for the latest driver, software and document.

Note:

(*): Please refer what model you have purchased.

(**): For ExpressCard model only.